

Figure 1 (PRIOR ART)

FIG. 2 (PRIOR ART)




FIG. 3




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 4D




FIG. 5




FIG. 6




FIG. 7





FIG. 8



REMOVE CLIP,
AND REINSTALL
HEAT EXCHANGER
IN TESTER

PLACE HEAT EXCHANGER
ON HOT PLATE

REMOVE
HEAT EXCHANGER
FROM HOT PLATE
WHEN SOLDER
LAYER MELTS

FIG. 9




FIG. 10A




FIG. 10B




FIG. 11




FIG. 12




FIG. 13




FIG. 14

